

DMP System Messages

id	message	EventType	isRestoral
101	Device Missing	AUTOLOG (33)	False
102	Device Restored	AUTOLOG (33)	False
150	Abort by User	ABORT (10)	False
171	UL Open Indicator	AUTOLOG (33)	False
172	UL Close Indicator	AUTOLOG (33)	False
S00	AC Power Restore	TRBL-AC (7)	True
S01	Low Battery Restore	TRBL-BAT (8)	True
S02	Communication Line Level Restored	TRBL-BAT (8)	True
S03	Panel Tamper Restored	TECHNICIAN (27)	False
S04	Backup Communication Line Restored	TRBL-LINE (9)	True
S05	Panel Ground Restored	TECHNICIAN (27)	True
S06	Not Armed by Scheduled Time	TECHNICIAN (27)	False
S07	Automatic Test	TEST (11)	False
S08	AC Power Failure	TRBL-AC (7)	False
S09	Low Standby Battery	TRBL-BAT (8)	False
S10	Low Comm Line Level	TRBL-LINE (9)	False
S11	Panel Tamper	TECHNICIAN (27)	False
S12	Panel Backup Comm Fail	TRBL-LINE (9)	False
S13	Panel Ground Fault	TECHNICIAN (27)	False
S14	Non-Alarm Message Overflow	AUTOLOG (33)	False
S15	Silent Panic (Ambush)	DURESS (14)	False
S16	Panel Not Responding	NO CHECKIN (36)	False
S17	Panel Response Restored	NO CHECKIN (36)	True
S18	Zone Alarm Overflow	AUTOLOG (33)	False
S19	New Panel on Line	AUTOLOG (33)	False
S20	Carrier Locked on Line	AUTOLOG (33)	False
S21	Message Not Acknowledged	AUTOLOG (33)	False
S22	Carrier Off, Multiplex Line Restored	AUTOLOG (33)	False
S23	Manual Test	TEST (11)	False
S24	SCS1 Test Signal Not Received	AUTOLOG (33)	False
S25	SCS1 Power Up Signal Received	AUTOLOG (33)	False
S26	Auxiliary Fuse Trouble	TROUBLE (6)	False
S27	Auxiliary Fuse Restored	TROUBLE (6)	True
S28	Telephone Line 1 Trouble	TRBL-LINE (9)	False
S29	Telephone Line 1 Restore	TRBL-LINE (9)	True
S30	Telephone Line 2 Trouble	TRBL-LINE (9)	False
S31	Telephone Line 2 Restore	TRBL-LINE (9)	True
S32	Trouble Alert Silenced	AUTOLOG (33)	False
S33	Trouble Alert Returned to Normal	AUTOLOG (33)	False
S34	Alarm Bell Silenced	AUTOLOG (33)	False
S35	Alarm Bell Returned to Normal	AUTOLOG (33)	False
S36	Time/Day Set by Operator	AUTOLOG (33)	False
S37	Security Information Management Startup	AUTOLOG (33)	False
S38	Bell Circuit Trouble	TROUBLE (6)	False
S39	Bell Circuit Restored	TROUBLE (6)	True
S40	Fire Zone Alarm Overflow	AUTOLOG (33)	False
S41	Panic Zone Alarm Overflow	AUTOLOG (33)	False
S42	Burglary Zone Alarm Overflow	AUTOLOG (33)	False
S43	Bell Fuse Trouble	TROUBLE (6)	False
S44	Fire-Burglary Trouble Overflow	AUTOLOG (33)	False
S45	Abort	ABORT (10)	False
S46	Zone Swinger Automatically Bypassed	AUTOLOG (33)	False
S47	Zone Swinger Automatically Restored	AUTOLOG (33)	False
S48	Low Battery Cutoff	TRBL-BAT (8)	False
S49	Abort	ABORT (10)	False
S50	Supervised Wireless Trouble	TRBL-SUP (26)	False

S51 Zone Interrogation Trouble	AUTOLOG (33)	False
S52 Signal Disabled by Operator	AUTOLOG (33)	False
S53 Bell Fuse Restored	TROUBLE (6)	True
S54 Unsuccessful Remote Connect	AUTOLOG (33)	False
S55 Internal Message	AUTOLOG (33)	False
S56 Control Panel Trapped	AUTOLOG (33)	False
S57 Message Pending	AUTOLOG (33)	False
S58 Panel Substitution	AUTOLOG (33)	False
S59 Substitution/Checkin Overflow	AUTOLOG (33)	False
S60 Redundant Receiver Failure	AUTOLOG (33)	False
S61 Comm Trouble Line 1	SUPERVISORY (32)	False
S62 Comm Trouble Line 3	SUPERVISORY (32)	False
S63 Comm Trouble Line 3	SUPERVISORY (32)	False
S64 Comm Trouble Line 5	SUPERVISORY (32)	False
S65 Comm Trouble Line 5	SUPERVISORY (32)	False
S66 System Test Begin	AUTOLOG (33)	False
S67 System Test End	AUTOLOG (33)	False
S68 Receiver Printer Failed	AUTOLOG (33)	False
S69 Receiver Printer Restore	AUTOLOG (33)	False
S70 End of History Buffer	AUTOLOG (33)	False
S71 Request for Receiver Time and Date	AUTOLOG (33)	False
S72 Network Trouble	TECHNICIAN (27)	False
S73 Network Restored	TECHNICIAN (27)	True
S74 Tamper During Armed State	TECHNICIAN (27)	False
S75 SIMS Operator Acknowledge Fail	AUTOLOG (33)	False
S76 SIMS Operator Acknowledge Restore	AUTOLOG (33)	False
S77 Unauthorized Entry	AUTOLOG (33)	False
S78 System Recently Armed	AUTOLOG (33)	False
S79 Signal During Opened Period	AUTOLOG (33)	False
S80 Exit Error	EXITFAULT (28)	False
S81 DDMX - Connect	AUTOLOG (33)	False
S82 DDMX - Disconnect	AUTOLOG (33)	False
S83 Remote Programming Complete	AUTOLOG (33)	False
S84 Remote Command Received	AUTOLOG (33)	False
S85 DDMX - Redundant	AUTOLOG (33)	False
S86 Local Programming	AUTOLOG (33)	False
S87 Comm Fail Restored	TRBL-LINE (9)	True
S88 Abnormal Test	TECHNICIAN (27)	False
S89 Supervised Wireless Restored	TRBL-SUP (26)	True
S90 Unrecognized Message	AUTOLOG (33)	False
S91 Service Requested	TECHNICIAN (27)	False
S92 No Arm/Disarm Activity	TECHNICIAN (27)	False
S93 User Activity Not Detected	AUTOLOG (33)	False
S94 Activity Check Enabled	AUTOLOG (33)	False
S95 Activity Check Disabled	AUTOLOG (33)	False
S96 System Message 96	AUTOLOG (33)	False
S97 Network Communication Test OK	AUTOLOG (33)	False
S98 SCS-1 Memory Full	AUTOLOG (33)	False
S99 System Check	AUTOLOG (33)	False

DMP Serial1 Messages

EventType	ZoneType	Description	EventType	isRestoral	SignalType	Pattern	id
A	0		ALARM (12)	False	Zone (2)	zzzz2/	1
A	1		FIRE (0)	False	Zone (2)	zzzz2/	2
A	2		BURG (2)	False	Zone (2)	zzzz2/	3
A	3	Supervisory	SUPERVISORY (32)	False	Zone (2)	zzzz2/	4
A	4		PANIC(audible) (1)	False	Zone (2)	zzzz2/	5
A	5	Emergency	MEDICAL (13)	False	Zone (2)	zzzz2/	6

A	6	Auxiliary 1	ALARM (12)	False	Zone (2)	zzzz2/	7
A	7	Auxiliary 2	ALARM (12)	False	Zone (2)	zzzz2/	8
B		Force Arm	BYPASS (5)	False	Zone (2)	zzzzx/	41
C			CLOSE (4)	False	User (1)	uuuuaa/	49
D		XMTR Low Battery	TRBL-SUP (26)	False	Zone (2)	zzzzx/	44
E		Equipment Message	AUTOLOG (33)	False	Unknown (0)	mmmmmxzzzzx	61
e		Equipment Message	AUTOLOG (33)	False	Unknown (0)	mmmmmxzzzzx	62
F		Walk Test FAIL	AUTOLOG (33)	False	Zone (2)	zzzzx/	33
H		XMTR Missing	TRBL-SUP (26)	False	Zone (2)	zzzzx/	45
i		Secondary Sched Changed	AUTOLOG (33)	False	Unknown (0)	xxuuuuxxxxxxxxax	59
l		Temporary Sched Changed	AUTOLOG (33)	False	Unknown (0)	xxuuuuxxxxxxxxax	57
J		Door Access Granted	AUTOLOG (33)	False	User (1)	uuuuzz	55
K		Walk Test OK	AUTOLOG (33)	False	Zone (2)	zzzzx/	25
L		Late to Arm	TECHNICIAN (27)	False	Area (3)	xxxxaa/	50
M		Service Man	AUTOLOG (33)	False	Unknown (0)	zzzzz	60
N		Permanent Sched Changed	AUTOLOG (33)	False	Unknown (0)	xxuuuuxxxxxxxxax	56
n		Primary Sched Changed	AUTOLOG (33)	False	Unknown (0)	xxuuuuxxxxxxxxax	58
O			OPEN (3)	False	User (1)	uuuuaa/	48
P		Code Addition	AUTOLOG (33)	False	Unknown (0)	uuuuzzzz	51
p		Code Deletion	AUTOLOG (33)	False	Unknown (0)	uuuuzzzz	53
R	0		ALARM (12)	True	Zone (2)	zzzz2/	17
R	1		FIRE (0)	True	Zone (2)	zzzz2/	18
R	2		BURG (2)	True	Zone (2)	zzzz2/	19
R	3		SUPERVISORY (32)	True	Zone (2)	zzzz2/	20
R	4		PANIC(audible) (1)	True	Zone (2)	zzzz2/	21
R	5	Emergency Zone Rest	MEDICAL (13)	True	Zone (2)	zzzz2/	22
R	6	Auxiliary 1 Rest	ALARM (12)	True	Zone (2)	zzzz2/	23
R	7	Auxiliary 2 Rest	ALARM (12)	True	Zone (2)	zzzz2/	24
s		System Message	AUTOLOG (33)	False	Unknown (0)	ccczzz	63
T	0		TROUBLE (6)	False	Zone (2)	zzzz2/	9
T	1		TRBL-FIRE (24)	False	Zone (2)	zzzz2/	10
T	2	Burg Zone Trbl	TROUBLE (6)	False	Zone (2)	zzzz2/	11
T	3		TRBL-SUP (26)	False	Zone (2)	zzzz2/	12
T	4	Panic Zone Trbl	TROUBLE (6)	False	Zone (2)	zzzz2/	13
T	5	Emergency Zone Trbl	TROUBLE (6)	False	Zone (2)	zzzz2/	14
T	6	Auxiliary 1 Trbl	TROUBLE (6)	False	Zone (2)	zzzz2/	15
T	7	Auxiliary 2 Trbl	TROUBLE (6)	False	Zone (2)	zzzz2/	16
U		Code Changed	AUTOLOG (33)	False	Unknown (0)	uuuuzzzz	54
v		Message	AUTOLOG (33)	False	Unknown (0)	xxxx/	64
W		Fault	TROUBLE (6)	False	Zone (2)	zzzzx/	43
X			BYPASS (5)	False	Zone (2)	zzzzuuuu/	46
Y		Bypass Restore	BYPASS (5)	True	Zone (2)	zzzzuuuu/	47

DMP Serial3 Messages

Type	SubType	Description	EventType	isRestoral	ID
a	\	Zone Alarm	UNDEFINED (22)	0	43
a	A1	Auxiliary 1	ALARM (12)	0	1
a	A2	Auxiliary 2	ALARM (12)	0	2
a	BL	Blank	UNDEFINED (22)	0	6
a	BU		BURG (2)	0	7
a	EM	Emergency	MEDICAL (13)	0	12
a	FI		FIRE (0)	0	13
a	PN		PANIC(audible) (1)	0	21
a	SV	Supervisory	SUPERVISORY (32)	0	32
b	\	Zone Force Arm	BYPASS (5)	0	44
d	\	Wireless Zone Low Battery	TRBL-SUP (26)	0	45
e	\	Equipment	AUTOLOG (33)	0	61
e	AD	Add	AUTOLOG (33)	0	34

e	AJ	Adjust	AUTOLOG (33)	0	36
e	RL	Replace	AUTOLOG (33)	0	23
e	RM	Remove	AUTOLOG (33)	0	35
e	RP	Repair	AUTOLOG (33)	0	24
e	TS		TEST (11)	0	37
f	\	Walk Test Zone Fail	TECHNICIAN (27)	0	46
g	\	Holidays	AUTOLOG (33)	0	58
h	\	Wireless Zone Missing	TRBL-SUP (26)	0	47
j	\	Door Access	AUTOLOG (33)	0	54
j	AA	Denied: Armed Area	AUTOLOG (33)	0	3
j	AP	Denied: Previous Access	AUTOLOG (33)	0	5
j	DA	Door Access Granted	AUTOLOG (33)	0	10
j	IA	Denied: Invalid Area	AUTOLOG (33)	0	14
j	IC	Denied: Invalid Code	AUTOLOG (33)	0	15
j	IL	Denied: Invalid Level	AUTOLOG (33)	0	16
j	IT	Denied: Invalid Time	AUTOLOG (33)	0	17
k	\	Walk Test Zone Verify	TECHNICIAN (27)	1	48
l	\	Schedules	AUTOLOG (33)	0	55
l	PE	Permanent Schedule	AUTOLOG (33)	0	20
l	PR	Primary Schedule	AUTOLOG (33)	0	22
l	S1	Shift One	AUTOLOG (33)	0	25
l	S2	Shift Two	AUTOLOG (33)	0	26
l	S3	Shift Three	AUTOLOG (33)	0	27
l	S4	Shift Four	AUTOLOG (33)	0	28
l	SE	Secondary Schedule	AUTOLOG (33)	0	29
l	TE	Temporary Schedule	AUTOLOG (33)	0	33
m	\	Service Man	TECHNICIAN (27)	0	62
m	SP	Stop Service Person	AUTOLOG (33)	0	30
m	ST	Start Service Person	AUTOLOG (33)	0	31
q	\	Arming Status	UNDEFINED (22)	0	56
q	CL		CLOSE (4)	0	9
q	LA	Area Late to Arm	TECHNICIAN (27)	0	18
q	OP		OPEN (3)	0	19
r	\	Zone Restore	RESTORE (23)	0	49
r	A1	Auxiliary 1 Restore	RESTORE (23)	0	70
r	A2	Auxiliary 2 Restore	RESTORE (23)	0	72
r	BL	Blank	AUTOLOG (33)	1	64
r	BU	Burg Restore	BURG (2)	1	66
r	EM	Emergency Restore	MEDICAL (13)	1	69
r	FI	Fire Restore	FIRE (0)	1	65
r	PN	Panic Restore	PANIC(audible) (1)	1	68
r	SV	Supervisory Restore	SUPERVISORY (32)	1	67
s	\	System Message	UNDEFINED (22)	0	63
t	\	Zone Trouble	TROUBLE (6)	0	50
t	SV	Supervisory	SUPERVISORY (32)	0	73
u	\	User Codes	AUTOLOG (33)	0	57
u	AD	User Code Added	AUTOLOG (33)	0	4
u	CH	User Code Changed	AUTOLOG (33)	0	8
u	DE	User Code Deleted	AUTOLOG (33)	0	11
w	\	Zone Fault	TROUBLE (6)	0	51
x	\	Zone Bypass	BYPASS (5)	0	52
y	\	Zone Reset	AUTOLOG (33)	0	53